

URL's and IP's used by PostBase

A: By the installer firmware (when requesting and receiving initial software sets as part of the installation)

ins.francotyp.com

ins2.francotyp.com

Both URLs currently resolve to **193.29.245.13**

B: By the US Application firmware (when executing services with the RSG/Repository e.g. remote diagnostics, remote feature setting, etc.)

mabusa.francotyp.com

mabusa2.francotyp.com

Both URLs currently resolve to **193.29.245.13**

C: By the US Application firmware (when executing services with the FPI e.g. PVDs, PVRs, and other IBIP-required functions)

mausa.francotyp.com

mausa2.francotyp.com

Both URLs currently resolve to **193.29.245.13**

D: By the US Application firmware and installer (when e.g. due to defect PSD no HTTPS session over the other URLs can be established. However, only remote diagnostic is then available)

busa.francotyp.com

busa2.francotyp.com

Both URLs currently resolve to **62.220.3.218**